DIAL INDICATOR STAND

6864-250

Unit: mm stem hole Ø8 fine adjustment serrated anvil 150(W)x100(D)

- Vertical travel of holder: 250mm
- Fine adjustment range: entire stroke
- Supplied with dust cover

Code	Applicable holding stem	Anvil
6864-250	Ø8mm	serrated, flatness 1.5µm, hardness HRC60±2

DIAL INDICATOR STANDS



- Vertical travel of holder: 100mm
- Fine adjustment range: 2mm
 Supplied with dust cover

Code	Applicable holding stem	Anvil
6862-1001	Ø8mm	serrated, flatness 1.5µm, hardness HRC60±2
6862-1002	Ø8mm	plain, flatness 1.5µm, hardness HRC60±2

fine adjustment 024

68

160

6862-1001

Ø58

stem hole Ø8

TRANSFER STAND



Rigid construction, designed to make comparison height measurement (set zero with gage block then measure height of workpiece) with dial indicators or digital indicators (variation of measuring force is high)



- Vertical travel of holder: 335mmFine adjustment range: 2mm
- Supplied with dust cover

	Unit: mm
ę	124
fine adjustment	holder 068
plain anvil Ø58	47

Code	Applicable holding stem	Anvil
6865-300	Ø8mm	plain, flatness 1.5µm, hardness HRC60±2